



Elkington


Axess Smoke Shaft Hatch

Facade hatch for safe and controlled smoke evacuation in hard-to-reach areas

Installation Instructions

1. Position the smoke shaft hatch in the desired location within the shaft.
2. Secure the frame using appropriate fasteners suitable for the substrate.
3. Ensure that the steel cable is properly and securely attached to the smoke shaft hatch.
4. Route the cable up to ground level and fasten it securely in a suitable location.

Function in Case of Smoke Release: When opening is required, pull the steel cable to release the hatch.



Always follow the specific installation instructions included with your order. Instructions may vary depending on model, material, and selected options. This document provides general recommendations for safe and correct installation of the unit.